

kaise

DIGITAL MULTIMETER

INSTRUCTION MANUAL

SK-6161/6163

KAISE CORPORATION

FOR SAFETY MEASUREMENTS!!

To prevent an electrical shock hazard to the operator and/or damage to the instruments, read this instruction manual carefully before using the instrument.

Important Symbols :

The symbol listed in IEC 61010-1 and ISO 3864 means "Caution (refer to instruction manual)".

WARNING

The symbol in this manual advises the user of an electrical shock hazard that could result in serious injury or even death.

CAUTION

The symbol in this manual advises the user of an electrical shock hazard that could cause injury or material damages.

WARNING

Do not measure High Power Line (High Energy Circuits). High Power Line is very dangerous and sometimes includes High Surge Voltage that could cause explosive short in the instrument and could result in serious injury to the operator.

INTRODUCTION

Thank you for purchasing KAISE "SK-6161/6163 DIGITAL MULTIMETER". To obtain the maximum performance of this instrument, read this Instruction Manual carefully, and take safe measurement.

1. UNPACKING AND INSPECTIONS

Confirm if the following items are contained in the package in good condition. If there is any damage or missing items, ask your local dealer for replacement.

- 1. Digital Multimeter 1 pce.
2. Test Lead (100-57) 1 set
3. Carrying Case (1020) 1 pce.
4. Spare Batteries (1.5V R6P, AA) 2 pcs.
5. Spare Fuses (0.5A/250V, 15A/250V) 1 pce. each
6. Instruction Manual 1 pce.

2. SPECIFICATIONS

2-1. GENERAL SPECIFICATIONS

- 1. DISPLAY (LCD)
a. Numerical Display : 4000 count, 20mm high
b. Units and Symbols : AUTO, -, ~, APO, DH, DIFF, Ω, kΩ, MΩ, Hz, %, nF, μF, mV, V, μA, mA, A, and decimal point
2. OPERATING PRINCIPLE : Δ conversion
3. RANGE SELECTION : Auto/Manual
4. POLARITY : Auto polarity ("-" sign when minus)
5. OVERLOAD INDICATION : "OL" display when exceeding 4000 count (2V in diode test)
6. BATTERY WARNING : indication at approx. 2.4V or less
7. OPERATING POWER SUPPLY VOLTAGE : approx. 2.4V or more and 3.6V or less
8. SAMPLING RATE : 2.5 times/second (except for Frequency, Duty Cycle and Capacitance measurement)
9. DISPLAY HOLD (SK-6163 only) : Hold indicating values by DH Key
10. DIFFERENCE MEASUREMENT (SK-6163 only) : Measurable by pressing DIFF Key for 1 second or more
11. DIELECTRIC STRENGTH : AC 3kVrms for 1 minute between input terminals and cases
12. OPERATING TEMPERATURE & HUMIDITY : 0°C to 40°C, less than 80%RH in non-condensing
13. STORAGE TEMPERATURE & HUMIDITY : -20°C to 60°C, less than 70%RH in non-condensing
14. TEMPERATURE COEFFICIENT : Accuracy at 23°C ± 5°C × 0.1%/°C
15. POWER SUPPLY : 1.5V R6P (AA) batteries × 2
16. POWER CONSUMPTION : approx. 6mW typ (70mW max.), approx. 0.03mW in Auto Power Off
17. CONTINUOUS OPERATING TIME : 300 hours or more

- 18. AUTO POWER OFF : Power turns off automatically after approx. 12 minutes (cancelable)
19. FUSE : μA, mA function : 0.5A/250V, φ5×20mm
20A function : 15A/250V, φ5×20mm
20. DIMENSIONS & WEIGHT : 160(H)×75(W)×34(D)mm, approx. 180g
21. ACCESSORIES : 100-57 Test Leads, 1020 Carrying Case, 1.5V R6P (AA) Batteries × 2, F14 Spare Fuse (0.5A/250V), F16 Spare Fuse (15A/250V), Instruction Manual
22. OPTIONAL ACCESSORIES : 660 AC/DC Clamp Adapter, 821 AC Clamp Adapter, 100-41 Test Lead Kit, 100-62 Test Lead Set, 940 Alligator Clip

2-2. MEASUREMENT SPECIFICATION

(23°C ± 5°C, <80%RH in non-condensing)

1. DC Voltage · Frequency · Duty Cycle (≡V · Hz · %)

1-1. DC Voltage (≡V)

Table with 7 columns: Range, Accuracy, Resolution, Input Impedance, Maximum Input, Range Selection, Overload Protection. Rows include 400.0mV, 4.000V, 40.00V, 400.0V, 1000V.

1-2. Frequency (Hz)

Table with 7 columns: Range, Accuracy, Resolution, Input Sensitivity, Maximum Input, Range Selection. Rows include 5.00Hz to 49.99Hz, 50.0Hz to 499.9Hz, 0.500kHz to 4.999kHz, 5.00kHz to 20.00kHz.

2-3. Duty Cycle (%)

Table with 7 columns: Range, Accuracy (40Hz to 500Hz), Resolution, Input Sensitivity, Maximum Input. Rows include 10.0% to 90.0%.

2. AC Voltage · Frequency · Duty Cycle (~V · Hz · %)

2-1. AC Voltage (~V)

Table with 7 columns: Range, Accuracy (40 to 500Hz), Resolution, Input Impedance, Maximum Input, Range Selection, Overload Protection. Rows include 4.000V, 40.00V, 400.0V, 750V.

Accuracy at 300Hz to 500Hz in 4.000V range : ±1.5%rdg±5dgt

2-2. Frequency (Hz)

Table with 7 columns: Range, Accuracy, Resolution, Input Sensitivity, Maximum Input, Range Selection. Rows include 5.00Hz to 49.99Hz, 50.0Hz to 499.9Hz, 0.500kHz to 4.999kHz, 5.00kHz to 20.00kHz.

2-3. Duty Cycle (%)

Table with 7 columns: Range, Accuracy (40Hz to 500Hz), Resolution, Input Sensitivity, Maximum Input. Rows include 10.0% to 90.0%.

3. Resistance (Ω)

Table with 7 columns: Range, Accuracy, Resolution, Test Current, Open Circuit Voltage, Range Selection, Overload Protection. Rows include 400.0Ω, 4.00kΩ, 40.00kΩ, 400.0kΩ, 4.000MΩ, 40.00MΩ.

4. Continuity Test (♪)

Table with 5 columns: Range, Buzzer Sound, Response Time, Open Circuit Voltage, Overload Protection. Rows include 400.0Ω.

5. Diode Test (➔)

Table with 5 columns: Range, Accuracy, Test Current, Open Circuit Voltage, Overload Protection. Rows include 1.000V.

6. Capacitance (⚡) ※SK-6163 only

Table with 6 columns: Range, Accuracy, Resolution, Test Voltage, Range Selection, Overload Protection. Rows include 50.00nF, 500.0nF, 5.000μF, 50.00μF, 100.0μF.

7. 20A Range : DC/AC Current · Frequency (≡A · ~A · Hz)

7-1. DC/AC Current (≡A / ~A)

Table with 7 columns: Range, Accuracy (AC: 40 to 500Hz), Resolution, Voltage Drop, Maximum Input, Range Selection, Overload Protection. Rows include 4.000A, 20.00A.

7-2. Frequency (Hz)

Table with 7 columns: Range, Accuracy, Resolution, Input Sensitivity, Maximum Input, Range Selection. Rows include 5.00Hz to 49.99Hz, 50.0Hz to 499.9Hz, 0.500kHz to 1.000kHz.

8. mA Range : DC/AC Current · Frequency (≡mA · ~mA · Hz)

8-1. DC/AC Current (≡mA / ~mA)

Table with 7 columns: Range, Accuracy (AC: 40 to 500Hz), Resolution, Voltage Drop, Maximum Input, Range Selection, Overload Protection. Rows include 40.00mA, 400.0mA.

8-2. Frequency (Hz)

Table with 7 columns: Range, Accuracy, Resolution, Input Sensitivity, Maximum Input, Range Selection. Rows include 5.00Hz to 49.99Hz, 50.0Hz to 499.9Hz, 0.500kHz to 1.000kHz.

9. μA Range : DC/AC Current · Frequency (≡μA · ~μA · Hz)

9-1. DC/AC Current (≡μA / ~μA)

Table with 7 columns: Range, Accuracy (AC: 40 to 500Hz), Resolution, Voltage Drop, Maximum Input, Range Selection, Overload Protection. Rows include 400.0μA, 4000μA.

9-2. Frequency (Hz)

Table with 7 columns: Range, Accuracy, Resolution, Input Sensitivity, Maximum Input, Range Selection. Rows include 5.00Hz to 49.99Hz, 50.0Hz to 499.9Hz, 0.500kHz to 1.000kHz.

3. SAFETY PRECAUTIONS

3-1. WARNINGS

Correct knowledge of electric measurements is essential to avoid unexpected danger such as operator's injury or damage to the instrument. Read carefully and observe the following precautions for safety measurements.

WARNING 1. Checks of Body and Test Lead

Before measurement, confirm the body of this instrument and handle insulators of the Test Lead have no cracks or any other damages. Dust, grease and moisture must be removed.

WARNING 2. High Power Line Measurements is Prohibited

Do not measure High Power Line (High Energy Circuits) such as Distribution Transformers, Bus Bars and Large Motors. High Power Line sometimes includes High Surge Voltage that could cause explosive short in the instrument and could result in shock hazard.

WARNING 3. Warning for High Voltage Measurements

Even for Low Energy Circuits of electric/electronic appliances, such as heating elements, small motors, line cords and plugs, High Voltage Measurements are very dangerous. Do not touch any part of the circuit.

WARNING 4. Dangerous Voltage Measurement Procedure

For dangerous voltage measurement, strictly observe the warnings below.


See Fig-1

- Do not hold the instrument in your hands.
Keep safety distance from power source or circuit to be measured not to touch the dangerous voltage.
Attach black and red alligator clips to test lead pins.
Turn off the circuit to be measured when connecting the test leads.
After finishing the measurement, turn off the circuit to be measured again and discharge the all capacitors. Then, detach alligator clips (test leads) from the circuit.

In case of live-line measurement, strictly observe the warnings below

See Fig-2

- Do not hold the instrument in your hands.
Keep safety distance from power source or circuit to be measured not to touch the dangerous voltage.
Black test lead : Attach black alligator clip and connect to - (earth) side of the circuit.
Red test lead : Connect to + (positive) side of the circuit.



3-2. PREVENTION OF FAILURE

WARNING 1. Correct Selection of Function Switch

Always confirm that FUNCTION Switch is set to the correct position. Do not measure voltage except at Voltage measurement function.

WARNING 2. Maximum Input Observance

Do not measure anything that might exceed the specified maximum input values.


WARNING 3. Test Lead Detachment

Detach test leads from the measuring circuit when changing measurement functions or removing rear case for battery or fuse replacement.

3-3. GENERAL WARNINGS AND CAUTIONS

- WARNING 1. Children and the persons who do not have enough knowledge about electric measurements must not use this instrument.
WARNING 2. Do not measure the electricity naked or barefooted to protect yourself from electrical shock hazard.
WARNING 3. Be careful not to get hurt with the sharp test lead pins.
CAUTION 1. Keep away the instrument from hot and humid conditions like in the car. Do not apply hard mechanical shock or vibration.
CAUTION 2. Do not polish the case or attempt to clean it with any cleaning fluid like gasoline or benzene. If necessary, use silicon oil or antistatic fluid.
CAUTION 3. Remove the batteries when the instrument is out of use for a long time. The exhausted battery might leak electrolyte and corrode the inside.

4. NAME ILLUSTRATION



※The illustration is SK-6163.

Fig-3

4-1. LCD




Fig-4

- AUTO : Auto-ranging
Low battery warning
Direct Current
Minus
Alternative Current
APO : Lights up in Auto Power Off mode
DH : Lights up in Display Hold function (SK-6163 only)
DIFF : Lights up in Difference measurement (SK-6163 only)
Continuity test
Diode test
Resistance measurement (Ω, kΩ, MΩ)
Frequency measurement (Hz)
Duty cycle measurement (%)
Capacitance measurement (nF, μF)
Voltage measurement (mV, V)
Current measurement (μA, mA, A) (SK-6163 only)

4-2. FUNCTION SWITCH

The switch to turn on the instrument and to select measurement functions. After finishing the measurement, turn it to "OFF".

WARNING

- Always confirm that FUNCTION Switch is set to the correct position. Do not measure voltage except at Voltage measurement function.
To prevent electric shock or damage of this unit, detach test leads from measuring circuit before changing measurement functions.

4-3. SELECT Key

Use this Key to select sub-measurement functions in the following measurement. Functions are changed as follows each time when the SELECT Key is pressed.

- Voltage measurement : ≡V or ~V → Hz → % → ≡V or ~V
Current measurement (A / mA / μA) : ≡A → ~A → Hz → ≡A
Diode test / Capacitance measurement (SK-6163 only) : ➔ → ⚡

4-4. RANGE Key

Manual-range measurement is possible by pressing this key during the auto-range measurement ("AUTO" disappears from LCD). To change the measurement range in manual-range, press RANGE Key. Check decimal point and select the suitable ranges.

To return to Auto-range : Press RANGE Key for 1 second or more. ("AUTO" lights up).

NOTE : RANGE Key is available for DC/AC Voltage, resistance and DC/AC current measurements.

4-5. DH Key : Display Hold ※SK-6163 only

Press this key to hold displayed value on LCD. (" DH " lights up).

To release it : Press DH Key again.

4-6. DIFF Key : Difference measurement

※shares with DH Key, SK-6163 only

Press **DIFF Key** for 1 second or more to start difference measurement ("DIFF" lights up). Measurement value displayed on LCD is converted into 0 ± 1 digit, and the relative value is displayed.

To release it : Press **DIFF Key** for 1 second or more again. Difference measurement is finished and returns to the normal measurement mode.

4-7. Input terminals • Test lead

Insert black test lead to COM terminal and red test lead to the other terminals.

NOTE : Insert RED test lead to 20A terminal when measuring in DC/AC 20A ranges.

5. MEASUREMENT PROCEDURES

5-1. PREPARATION FOR USE

1. INSTRUCTION MANUAL

Read INSTRUCTION MANUAL carefully to understand the specification and functions correctly. "3. SAFETY PRECAUTIONS" is very important for safety measurement.

2. BATTERY

Two 1.5V R6P (AA) batteries are installed in this instrument. When "BAT" lights up on LCD, replace them into the new ones in reference to "6-1. BATTERY AND FUSE REPLACEMENT".

3. FUSE

0.5A/250V and 15A/250V fuses are installed to protect current measurement function. Replace them in reference to "6-1. BATTERY AND FUSE REPLACEMENT" when blown out.

4. OVERLOAD INDICATION

LCD displays "OL" when measurement value exceeds 4000 count (2V in Diode Test).

5. AUTO POWER OFF

Power turns off automatically after approx. 12 minutes of last operation.

NOTE : Small power consumption (approx. 0.03mW) remains even in the auto power off condition. Be sure to set **FUNCTION Switch** to "OFF" after finishing the measurement.

To cancel it : Turn on the instrument holding down **SELECT Key**. ("APO" disappears)

5-2. DC VOLTAGE • FREQUENCY • DUTY CYCLE MEASUREMENT ($\approx V \cdot Hz \cdot \%$)

WARNING

- Do not measure High Power Line or high power circuit.
- Do not measure any voltage that might exceed maximum input value.
- Confirm the **FUNCTION Switch** is set to the correct position before measurement.
- Read "3. SAFETY PRECAUTIONS" carefully to avoid electric shock hazard and serious damage to the instrument.

- Insert black test lead to COM terminal, and insert red test lead to V terminal.
- Set **FUNCTION Switch** to " $\approx V_{Hz/\%}$ ".
NOTE : LCD display might be drifting at this time due to the high input impedance of this instrument, but does not affect the measurement.
- Connect black test lead to - (earth) side of the circuit being measured and connect red test lead to + (positive) side.
NOTE : Connect the instrument **IN PARALLEL** to the circuit.
NOTE : Use alligator clips (option) for dangerous voltage measurement.
- Read the measurement value on LCD.
- After finishing the measurement, set **FUNCTION Switch** to "OFF".

FREQUENCY MEASUREMENT (Hz) :

Frequency (Hz) can be measured by pressing **SELECT Key** during DC voltage measurement.

DUTY CYCLE MEASUREMENT (%) :

Duty cycle (%) can be measured by pressing **SELECT Key** during frequency measurement. Press **SELECT Key** again to return to DC voltage measurement.

AVAILABLE FUNCTIONS :

Range hold, Display hold (SK-6163 only), Difference measurement (SK-6163 only)




Fig-5

5-3. AC VOLTAGE • FREQUENCY • DUTY CYCLE MEASUREMENT ($\sim V \cdot Hz \cdot \%$)

WARNING

- Do not measure High Power Line or high power circuit.
- Do not measure any voltage that might exceed maximum input value.
- Confirm the **FUNCTION Switch** is set to the correct position before measurement.
- Read "3. SAFETY PRECAUTIONS" carefully to avoid electric shock hazard and serious damage to the instrument.

- Insert black test lead to COM terminal, and insert red test lead to V terminal.
- Set **FUNCTION Switch** to " $\sim V_{Hz/\%}$ ".
NOTE : LCD display might be drifting at this time due to the high input impedance of this instrument, but does not affect the measurement.
- Connect black test lead to - (earth) side of the circuit being measured and connect red test lead to + (positive) side.
NOTE : Connect the instrument **IN PARALLEL** to the circuit.
NOTE : Use alligator clips (option) for dangerous voltage measurement.
- Read the measurement value on LCD.
- After finishing the measurement, set **FUNCTION Switch** to "OFF".

FREQUENCY MEASUREMENT (Hz) :

Frequency (Hz) can be measured by pressing **SELECT Key** during AC voltage measurement.

DUTY CYCLE MEASUREMENT (%) :

Duty cycle (%) can be measured by pressing **SELECT Key** during frequency measurement. Press **SELECT Key** again to return to AC voltage measurement.

AVAILABLE FUNCTIONS :

Range hold, Display hold (SK-6163 only), Difference measurement (SK-6163 only)




Fig-6

5-4. RESISTANCE MEASUREMENT (Ω)

WARNING

- Confirm the **FUNCTION Switch** is set to the correct position.
- Do not measure voltage in Ω position. This will cause electrical shock hazard to the operator and/or serious damage to the instrument.
- In case in-circuit resistance is measured, turn off the power to the circuit being measured and discharge the all capacitors.
- Read "3. SAFETY PRECAUTIONS" carefully before measurement.

- Insert black test lead to COM terminal and insert red test lead to Ω terminal.
- Set **FUNCTION Switch** to " Ω ".
- If the resistor to be measured is connected in a circuit, turn off the power to the circuit and discharge the all capacitors. Then, disconnect one side of the resistor.
- Connect test leads to the resistor (or circuit) to be measured.
- Read the measurement value on LCD.
- After finishing the measurement, set **FUNCTION Switch** to "OFF".

AVAILABLE FUNCTIONS :

Range hold, Display hold (SK-6163 only), Difference measurement (SK-6163 only)




Fig-7

5-5. CONTINUITY TEST (\bullet)

WARNING

- Confirm the **FUNCTION Switch** is set to the correct position.
- Do not measure voltage in \bullet position. This will cause electrical shock hazard to the operator and/or serious damage to the instrument.
- When measuring in-circuit continuity, turn off the power to the circuit to be measured and discharge the all capacitors.
- Read "3. SAFETY PRECAUTIONS" carefully before measurement.

- Insert black test lead to COM Terminal and insert red test lead to \bullet terminal.
- Set **FUNCTION Switch** to " \bullet ".
- If testing continuity in a circuit, turn off the power to the circuit and discharge the all capacitors.
- Connect test lead to both side of the circuit to be measured. Buzzer sounds when the circuit resistance is approx. 60 Ω or lower.
- After finishing the measurement, set **FUNCTION Switch** to "OFF".

5-6. DIODE TEST (\rightarrow)

WARNING

- Confirm the **FUNCTION Switch** is set to the correct position.
- Do not measure voltage in \rightarrow (SK-6161) / \rightarrow (SK-6163) position. This will cause electrical shock hazard to the operator and/or damage to the instrument.
- If the diode is connected in a circuit, turn off the power to the circuit and discharge the all capacitors.
- Read "3. SAFETY PRECAUTIONS" carefully before measurement.

- Insert black test lead to COM terminal and insert red test lead to \rightarrow terminal.
- Set **FUNCTION Switch** to " \rightarrow " (SK-6161) / " \rightarrow " (SK-6163).
- If the diode is connected in a circuit, turn off the power to the circuit and discharge the all capacitors. Disconnect one side of the diode.
- Connect black test lead to Anode side and red test lead to Cathode side of the diode (Reverse connection). Confirm "OL" is displayed on LCD.
- Connect test leads to the opposite side of 4 (Forward Connection). Test results are good if the following voltage values are displayed on LCD.
 - Silicon diodes : 0.4V to 0.7V
 - Germanium diodes : 0.1V to 0.4V
- After finishing the measurement, set **FUNCTION Switch** to "OFF".




Fig-8

5-7. CAPACITANCE MEASUREMENT (\rightarrow) ※SK-6163 only

WARNING

- Confirm the **FUNCTION Switch** is set to the correct position.
- Do not measure voltage in \rightarrow position. This will cause electrical shock hazard to the operator and/or damage to the instrument.
- If the capacitor is connected in a circuit, turn off the power to the circuit and discharge the all capacitors.
- Read "3. SAFETY PRECAUTIONS" carefully before measurement.

- Insert black test lead to COM terminal and insert red test lead to \rightarrow terminal.
- Set **FUNCTION Switch** to " \rightarrow ".
- Press **SELECT Key** three times to display the unit of "nF" on LCD.
- Press **DIFF Key** to reset the display into 0.000nF \pm 3dgt.
- If the capacitor is connected in a circuit, turn off the power to the circuit and discharge the all capacitors. Then, disconnect one side of the capacitor.
- Connect test lead to both side of the capacitor to be measured. Read the measurement value on LCD.

NOTE : High capacitance capacitor should be taken longer to get a measurement value.

After finishing the measurement, set **FUNCTION Switch** to "OFF".

AVAILABLE FUNCTIONS : Display hold (SK-6163 only)

5-8. CURRENT • FREQUENCY MEASUREMENT ($\approx A / \approx mA / \approx \mu A \cdot Hz$)

WARNING

- Do not measure High Power Line high power circuit.
- Do not measure the current that exceeds the maximum input value.
- Confirm the **FUNCTION Switch** is set to the correct position.
- Do not measure voltage in $\approx 20A Hz / \approx mA Hz / \approx \mu A Hz$ positions. This will cause electrical shock hazard to the operator and/or damage to the instrument.
- Read "3. SAFETY PRECAUTIONS" carefully before measurement.
- Be sure to connect RED test lead to 20A terminal in $\approx 20A$ measurement.
- Continuous loading time of 20A (maximum input value) in $\approx 20A$ measurement is within 30 seconds.

- Insert black test lead to COM terminal and insert red test lead μA , mA or 20A terminal.
NOTE : RED test lead must be connected to 20A terminal in $\approx 20A$ measurement.
- Set **FUNCTION Switch** to " $\approx 20A Hz$ ", " $\approx mA Hz$ " or " $\approx \mu A Hz$ ". Select the suitable position depending on the amount of the measurement current.
- Press **SELECT Key** once to measure AC current.
- Turn off the power of the circuit to be measured. Open the circuit after discharging the capacitors.
- Connect black test lead to - (earth) side and connect red test lead to + (positive) side of the circuit to be measured.
NOTE : Connect the instrument **IN SERIES** to the circuit.
NOTE : Use alligator clips (option) for dangerous current measurement.
- Turn on the power of the circuit to be measured. Read the measurement value on LCD.
- Turn off the power of the circuit to be measured and discharge the all capacitors. Set **FUNCTION Switch** to "OFF".

FREQUENCY MEASUREMENT (Hz) :

Frequency (Hz) can be measured by pressing **SELECT Key** during $\approx 20A / \approx mA / \approx \mu A$ measurement. Press twice in DC current measurement, press once in AC current measurement.

AVAILABLE FUNCTIONS :

Range hold, Display hold (SK-6163 only), Difference measurement (SK-6163 only)

6. MAINTENANCE

6-1. BATTERY AND FUSE REPLACEMENT

WARNING

- To avoid electrical shock, replace batteries and fuses after finishing measurement.
- Detach test leads from circuit and input terminals and set **FUNCTION Switch** to "OFF".
- Always use the specified fuse. Do not use this instrument shorting fuse holder or without using the fuse.

FUSE SPECIFICATION : 0.5A/250V ($\phi 5 \times 20mm$) and 15A/250V ($\phi 5 \times 20mm$)

- Detach test leads from input terminals and set **FUNCTION Switch** to "OFF".
- Loosen a screw on the rear case and remove the rear case from the bottom side.
- Remove the exhausted batteries and insert 2 pcs of new 1.5V R6P (AA) batteries in the correct polarity.
- When replacing fuses, replace blown fuses into new ones.
NOTE : The fuse rating is stamped on the metal part of the fuse edge. Install the suited fuse after confirming the fuse rating carefully because 0.5A fuse and 15A fuse are the same size.
- Fix rear case onto the front case from upper side fitting their hooks and tighten a screw.




Fig-9

NOTE : Remove the batteries when the instrument is out of use for a long time. The exhausted battery might leak electrolyte and corrode the inside.

6-2. PERIODICAL CHECK AND CALIBRATION

Periodical check and calibration is necessary to make safety measurements and to maintain the specified accuracy. The recommended check and calibration term is once a year and after the repair service. This service is available at **KAISE AUTHORIZED SERVICE AGENCY** through your local dealer.

6-3. REPAIR

Repair service is available at **KAISE AUTHORIZED SERVICE AGENCY** through your local dealer. Pack the instrument securely with your name, address, telephone number and problem details, and ship prepaid to your local dealer.

Check the following items before asking repair service.

- Check the battery connection, polarity, and capacity.
- Check if the fuse does not blow out or not drop off from the fuse holder.
- Confirm that the **FUNCTION Switch** is set correctly.
- Confirm if the over input, exceeding the specified range value, is not applied.
- Confirm that measured accuracy is adopted in the operating environment.
- Confirm that the body of this instrument and test leads have no cracks or any other damages.
- Check if the instrument is not affected by the strong noise generated from the equipment to be measured or measuring surroundings.

WARRANTY

SK-6161/6163 is warranted in its entirety against any defects of material or workmanship under normal use and service within a period of one year from the date of purchase of the original purchaser. Warranty service is available at **KAISE AUTHORIZED SERVICE AGENCY** through your local dealer. Their obligation under this warranty is limited to repairing or replacing SK-6161/6163 returned intact or in warrantable defect with proof of purchase and transport charges prepaid. **KAISE AUTHORIZED DEALER** and the manufacturer, **KAISE CORPORATION**, shall not be liable for any consequential damages, loss or otherwise. The foregoing warranty is exclusive and in lieu of all other warranties including any warranty of merchantability, whether expressed or implied. This warranty shall not apply to any instrument or other article of equipment which shall have been repaired or altered outside of **KAISE AUTHORIZED SERVICE AGENCY**, nor which have been subject to misuse, negligence, accident, incorrect repair by users, or any installation or use not in accordance with instructions provided by the manufacturer.

KAISE AUTHORIZED DEALER

KAISE CORPORATION

422 Hayashinogo, Ueda City, Nagano Pref., 386-0156 Japan

TEL : +81-268-35-1601 / FAX : +81-268-35-1603

E-mail : sales@kaise.com http://www.kaise.com

Product specifications and appearance are subject to change without notice due to continual improvements.