



# User Manual

## RISHABH 410

### Digital Multimeters







## **Multimeter Operating Elements**

- 1 LCD Display
- 2 Multifunction Pushbutton ( yellow key)
- 3 Pushbutton for Relative value
- 4 Pushbutton for Automatic or Manual range selection
- 5 Hz/% Pushbutton for VAC & VDC.
- 6 Data HOLD Pushbutton
- 7 Backlight Pushbutton (optional).
- 8 Function Selector Switch for ON/OFF and Measurement Function Selection
- 9 Terminal Sockets

## **LCD Display**

- 1 Digital Display with Indication of Decimal Point and Polarity
- 2 Display of Selected Current /voltage Type
- 3 Display for Automatic Measuring Range Selection
- 4 REL, HOLD Display
- 5 Continuity Test Display: Buzzer Indication
- 6 Diode Measurement Display
- 7 Low Battery Display
- 8 Display for Unit of Measured Quantity

<b>Contents</b>	<b>Page</b>
<b>1. Safety Features and Precautions .....</b>	<b>4</b>
<b>2. Initial Start-up .....</b>	<b>6</b>
<b>3. Selecting Measuring Functions &amp; Ranges ....</b>	<b>7</b>
3.1 Measuring Function Selection.....	7
3.2 Automatic Measuring Range Selection.....	8
3.3 Manual Measuring Range Selection.....	8
<b>4. Liquid Crystal Display .....</b>	<b>9</b>
4.1 Digital Display .....	9
4.2 Display with Backlit(optional).....	9
<b>5.0 Buzzer .....</b>	<b>10</b>
<b>6.0 Measurement Value Storage "HOLD".....</b>	<b>10</b>
<b>7.0 REL - Relative value measurement .....</b>	<b>10</b>
<b>8.0 Voltage Measurement .....</b>	<b>10</b>
<b>9.0 Current Measurement .....</b>	<b>12</b>
9.1 AC Measurement with (Clip-on) C.T. ....	13
<b>10.0 Diode Testing &amp; Continuity Measurement ....</b>	<b>14</b>
10.1 Diode Testing .....	14
10.2 Continuity Testing .....	15
<b>11.0 Resistance Measurement .....</b>	<b>16</b>
<b>12.0 Capacitance Measurement .....</b>	<b>17</b>
<b>13.0 Frequency &amp; Duty cycle Measurement .....</b>	<b>19</b>
13.1 Frequency Measurement .....	19
13.2 Duty Cycle Measurement .....	19
<b>14.0 Temperature Measurement .....</b>	<b>20</b>
<b>15.0 Specifications .....</b>	<b>21</b>
<b>16.0 Maintenance .....</b>	<b>26</b>
16.1 Battery .....	26
16.2 Fuses .....	27
16.3 Housing .....	28
<b>17.0 Repair and Replacement parts service .....</b>	<b>28</b>

## 1 Safety Features and Precautions

You have selected an instrument which provides you with a high level of safety.

The digital multimeter is manufactured in compliance with safety regulations. In case of incorrect use or careless handling, the safety of both user and multimeter is not assured.




**To maintain the safe and proper condition of the meters and to ensure their safe operation, it is absolutely necessary to carefully and completely read these operating instructions before using any meter. These instructions must be followed in all respects.**

Observe the following safety precautions:

- The meter must only be operated by persons who understand the danger of shock hazards and know how to apply safety precautions. Shock hazards exist anywhere, where voltages of more than 30 V (TRMS) may occur.
- Do not work alone in shock hazardous environment while carrying out measurement
- *The maximum allowable voltage* between any terminal sockets (1) and earth is equal to 1000 V. Voltages of greater than 500 V may only be applied to sockets “ $\perp$ ”, and “V” with the selector switch in the voltage measurement position (selector switch in “V” position).
- Take in to account that unexpected voltages can occur at devices under test (e.g. defective devices). For example, capacitors can be dangerously charged.

- Verify that the test leads are in good condition, e.g. no cracked insulation, no open circuits in the leads or connectors.
- This meter must not be used for measurements on circuits with corona discharge (high-voltage).
- Be particularly careful when measurements are made in HF electrical circuits. Dangerous composite voltages may be present.
- Measurements under moist ambient conditions are not permitted.
- Do not exceed the *permissible overload limits of the measuring ranges*. Limit values can be found in the table "Measuring Ranges" in chapter 15 "Specifications".
- All current ranges are equipped with fuses. The maximum allowable voltage for the measuring current circuit (= nominal voltage of the fuse) is equal to 600 V ~.
- **The instrument may only be used in power installations when the electrical circuit is protected with a 20 A fuse or circuit breaker, and the nominal voltage of the installation does not exceed 1000 V.**

#### Meaning of the symbols

	Warning of a danger point (Attention, refer to the user manual)
	Earth (ground) terminal.
	Double or reinforced insulation
CAT II / III	Instrument for over voltage category II / III or IV
CE	EU conformity mark.

## **Repair, Parts Replacement and Calibration**

After opening the meter, live parts may be exposed. Therefore, the meter must be disconnected from the measuring circuit prior to opening its case for repair, replacement of parts or calibration. If repair or calibration cannot be avoided unless the meter is open and live, this work must be performed by a qualified person who understands the danger involved.

## **Faults and Extraordinary Stress**

When it must be assumed that the safe operation is no longer possible, take the meter out of service and secure it against accidental use.

It is assumed that Safe operation is no longer possible,

- when the meter shows obvious sign of damage,
- when the meter no longer functions correctly,
- after a prolonged storage under adverse conditions,
- due to severe stress due to transportation.

## **2 Initial Start-Up**

### **Battery**

Fit the meter with battery (batteries) provided along with the meter

*Please see chapter 16.1, page 26, before initial start-up of your instrument, or after a lengthy period of storage.*

### **Switching the Meter ON**

Turn the Function selector switch from the OFF position to the desired measuring function.

All of the segments of LCD are activated briefly.

A drawing of the LCD can be found on page 1 .



**Note!**

Electrical discharge and high frequency interference can cause incorrect displays, and may block the measuring sequence. To reset, switch the meter off, and then back on. If this procedure is unsuccessful, briefly disconnect the battery from the contact terminals.

---

**Attention!**

*Before opening, disconnect the meter from the measuring circuit and observe chapter 16, page 26!*

---

**Automatic turn-OFF**

Your meter switches itself OFF automatically after 15 minutes, if no keys or the selector switch have been activated during this time.

**Switching the Meter back ON**

Activate the HOLD key.

**Switching the Meter OFF**

Turn the selector switch to the OFF position.

**3 Selecting Measuring Functions and Ranges****3.1 Measuring Function Selection**

The desired measuring function is selected with the Function selector switch ( white or yellow print) . In order to select the function printed in yellow color , the yellow multifunction key must also be pressed. If the multifunction key is pressed again, the function printed in white half circle is reactivated .

### 3.2 Automatic Measuring Range Selection

These multimeters features autoranging for all measuring ranges except for the ranges 400 mV  $\sim$  and 10 A. Automatic selection is functional as soon as the meter is switched ON. According to the measured quantity applied, the meter automatically selects the measuring range which gives the best resolution.

### 3.3 Manual Measuring Range Selection


You can switch OFF autoranging, select and fix the ranges manually according to the table given on page no. 9.

First select the desired measuring function with the functionselector switch and, if appropriate, the multifunction key.

Briefly activate the AUTO/MAN key.

Manual mode is switched OFF if you press and hold the AUTO/MAN key until you hear a second acoustic signal, and the display switches to AUTO.

When switching back to automatic operation in the 400 mV  $\sim$  range occurs, the 4 V  $\sim$  range is activated.



↓ AUTO/ MAN	Function	Acknowledge- ment	
		Display	Acoust. Signal
Brief	Manual Operation ON: Measuring Range is defined Switching Sequence at:		1 x
Brief	V $\overline{\text{---}}$ : 400 mV → 4 V → 40 V → 400 V → 1000 V → 400 mV → 4 V → ... V $\sim/$ : 4 V → 40 V → 400 V → 1000 V → 400 mV → ... mA $\overline{\text{---}}$ : 40 mA → 400 mA → 40 mA ... mA $\sim/$ : 40 mA → 400 mA → 40 mA ... $\Omega$ : 40 M $\Omega$ → 400 $\Omega$ → 4 k $\Omega$ → 40 k $\Omega$ → 400k $\Omega$ → 4 M $\Omega$ → 40 M $\Omega$ ...		1 x
Long	Return to Automatic Range Selection	AUTO	2x

*Note : For Temperature (°C), Frequency (Hz), Duty cycle (%) and Capacitance (F) measuring range is always Auto. No manual range selection is possible.*


## 4 Liquid Crystal Display

### 4.1 Digital Display

The digital display shows the measurement value, decimal point and sign. The selected measuring unit and function are displayed. When measuring DC quantities minus sign appears in front of the digits, if the positive pole of the measurement magnitude is applied to the “ $\perp$ ” input.

“OL” appears if the measuring range upper limit is exceeded. The digital display is updated thrice per second for V, A, W, Cap Freq and duty cycle measurements.

### 4.2 Display with Backlight (Optional)

By pressing  key back light can be made ON or OFF. User can take reading in poor light condition.

## 5 Buzzer

The following steps are acknowledged by an sound signal:

- Activation or deactivation of the following functions:  
AUTO/MAN, REL or HOLD , Hz\% , Backlight .
- When measuring AC Voltage > 750 V, DC Voltage > 1000 V, AC/DC mA > 400.0 mA, AC/DC A > 10 A, the buzzer will keep sounding as the overload warning.
- Approximate 1 minute before the meter is auto power off, the buzzer will raise constantly 5 sounds to warning.  
Before the meter is power off, the buzzer will raise one long sound to warn the user.

## 6 Measurement Value Storage "HOLD"

By pressing the HOLD key , the currently displayed measurement value can be "held", and "HOLD" is simultaneously displayed on the LCD.

The Hold display is switched OFF if:

- the Hold key is reactivated
- the function selector switch is operated
- the yellow multi function key is activated for a change of function, e.g. AC → DC.
- REL key is activated
- AUTO/MAN key is activated

## 7 REL - Relative value measurement

REL key is the key to measure relative value & it acts in activation. All functions can be used for Relative value Measurement except Hz / duty.

## 8 Voltage Measurement

Turn the Function selector switch to V $\overline{=}$

- 
- ⇨ Connect the measurement cable as shown. Terminal “⊥” should be grounded, and the second measuring cable with a higher potential connected to Terminal “V”.
- 

**Note!**

The measuring range 400 mV ~ can only be selected manually with the “AUTO/MAN” key!

---


**Attention!**

Make certain that the *current ranges* (“mA” or “A”) are deactivated and that the *measurement cables are connected to the correct terminals*, “V and ⊥”, before connecting your multimeter for the measurement of voltage! If the fuse tripping limit values are exceeded due to operator error, both the operator and the instrument are in danger! Observe the voltage limit values as printed on the meter !

---

Select the respective voltage type which corresponds to the measuring value by briefly pressing the yellow multifunction key. Each activation of the key causes alternate switching between AC and DC, as well as acknowledgement by means of an sound signal. The symbols DC and AC indicate the selected voltage type in the LCD display.

**After selection of this function with the selector switch, the voltage type DC is always activated.**



## 9 Current Measurement

---



### Attention!

First switch off the power supply to the measuring circuit and/or to the load, and discharge any capacitors which might be present.

---

a) Select function A with the function selector switch for currents  $> 400$  mA, or function mA for currents  $< 400$  mA. When measuring currents of an unknown magnitude, *Select the highest measuring range first.*

b) Select the function corresponding to the measured quantity by briefly pressing the yellow multi-function key. Each time the key is pressed, alternate switching takes place between AC and DC, and change over is acknowledged by sound signal. The symbols DC and AC indicate the selected current type in the LCD display.


**After selection of this function with the selector switch, the Current type DC is always activated.**

c) Connect the measuring instrument in series to the load as shown (without contact resistance).

### Notes on Current Measurement :

- The meter must be used only in power systems, when the current circuit is protected with a 20 A fuse or circuit breaker, and the nominal voltage of the system does not exceed 600 V.
- Make the measuring circuit connections mechanically strong and secure, so that they do not accidentally open. The conductor cross sections and connection points should be designed to avoid excessive heating.
- Current ranges up to 400 mA are protected with a FF1.6 A/600 V fuse.

- In the 400 mA measuring range an intermittent sound signal warns you, if the measurement value has exceeded the measuring range upper limit value.
- The 10 A current measuring range is protected with a 16 A/600 V fuse.
- If a fuse blows, eliminate the cause of the overload before placing the meter back into operation!
- Fuse replacement is described in chapter 16.2, page 27.



## 9.1 AC Measurement with (Clip-On) Current Transformers

### 9.1.1 Transformer Output mA/A




#### Attention!

If current transformers are operated with an open circuit on the secondary side, e.g. due to defective or disconnected leads, a blown fuse in the meter or a wrong connection, dangerously high voltages can occur at the connections. For this reason, verify that the current circuit of the multimeter and secondary winding of transformer connected to the multimeter form an intact circuit. Connect the transformer to the sockets  $\perp$  and mA/A

Some current transformers include safety devices, which prevent dangerous voltage increases at open electrical circuits. The maximum allowable operating voltage at the primary conductor is equal to the nominal voltage of the current transformer. When reading the measurement value, consider the transformation ration of the transformer, as well as additional display error.

### 9.1.2 Transformer Output mV/A.

Some transformers have a voltage output (designation: mV/A). Consequently, the secondary connection must be connected to  $\perp$  and V.



## 10 Diode Testing & Continuity Measurement

### 10.1 Diode Testing



#### Attention!

Verify that the device under test is electrically dead. External voltages would falsify the measurement results!

- \* Set the function selector switch to “  $\rightarrow$  ”.
- \* Connect the device under test as shown.



## Conducting Direction and Short-Circuit

The measuring instrument displays the forward voltage in volts. As long as the voltage drop does not exceed the maximum display value of 1.000 V, you can test several elements connected in series.

## Reverse Direction or Interruption

The measuring instrument displays a voltage of 'OL'




### Note!

Resistors and semiconductor paths in parallel to the diode distort the measurement results!

Conducting Direction



Reverse Direction



## 10.2 Continuity Testing



### Attention!


Verify that the device under test is electrically dead. External voltages would falsify the measurement results!

\* Set the selector switch to “→→”.

Press the yellow multifunction key to switch to the continuity measuring range. Display of the  $\Omega$  symbol is activated.

The instrument generates a continuous sound signal at a measured resistance of 0 ... approx. < 75  $\Omega$ .

\* Connect the Device Under Test as shown.



## 11 Resistance Measurement




### Attention!

Verify that the device under test is electrically dead. External voltages would falsify the measurement results!

\* Set the selector switch to “ $\Omega$ ”.

\* Connect the Device Under Test as shown.



### Zero Adjustment (Relative mode)

In the measurement of resistance the inherent error of the meter and the resistance of leads can be eliminated by zero adjustment.

- Short the leads connected to meter
- Press REL key

The instrument acknowledges zero adjustment with a sound signal & value close to 00 & REL are displayed on LCD.

The resistance measured at the moment the REL key is pressed serves as a reference value. This value is then automatically subtracted from all measured value.

### Deleting Zero Adjustment

Short the leads connected to meter and then press REL key.

or Activate the function selector switch.

or Switch the Multimeter off.

## 12 Capacitance Measurement




### Attention!

Be absolutely certain that the device under test is electrically dead. External voltages would falsify the measurement results!

Set the function selector switch to "F".


Connect the (discharged!) device under test to socket "⊥" and "F" with measurement leads. Polarized capacitors must be connected to the "⊥" socket at the "-" pole.



### Note!

Resistors and semiconductor paths in parallel to the capacitor falsify the measurement results!

To measure small value capacitors please use short measurement cables!

If  is displayed the measured values are not valid.

### **Zero Adjustment (relative mode)**

For the measurement of small capacitance values in the 5 nF and 50 nF ranges, the inherent error of the meter and the capacitance of the leads can be eliminated by zero adjustment.

-Connect the leads to the meter without Device under test.

-Briefly Press the REL key .

The instrument acknowledges zero adjustment with an sound signal, and a value close to "00.00" and REL are displayed at the LCD. The capacitance measured at the moment the key is activated serves as a reference value. This value is then automatically subtracted from all measured values.

### **Deleting Zero adjustment**

Press REL key

clearance is acknowledged by buzzer sound.

or     Activate the function selector switch

or     Switch the multimeter off.

## 13 Frequency & Duty Cycle Measurement

### 13.1 Frequency Measurement

- a) Set the function selector switch to VAC and press Hz/% key, as shown on page 20.  
The frequency measurement mode is activated. "Hz" symbol is displayed on the LCD. The digital display is expanded to 9999 digits. Only the auto mode is possible, no manual range is possible.
- b) Connections are made the same way as for voltage measurement.
- c) The lowest measurable frequencies and the maximum allowable voltages can be found in the chapter 15. Specifications"

### 13.2 Duty Cycle Measurement



- a) With duty cycle measurement, we can determine the ratio of pulse duration to cycle time of recurring square wave signals. The duty cycle that is the percentage pulse duration of signal is displayed on LCD i.e.
- $$\text{Duty cycle (\%)} = \frac{\text{pulse duration}}{\text{cycle duration}} \times 100$$

Note : The applied frequency must remain constant during the duty cycle measurement.

- a) Set the function selector switch to VAC and press Hz/% key twice as shown on page 20.  
The Duty cycle (%) mode is activated. "%" symbol is displayed on LCD.

**NOTE : Hz/% key is only applicable for VAC.**

- b) Connections are made the same way as for Voltage measurement
- c) measuring range for duty cycle and maximum allowable voltage can be found in chapter “Specifications”.




## 14 Temperature Measurement

Multimeter allows you to measure temperature with K-type thermocouple (NiCr-Ni) in the range  $0^{\circ}\text{C}$  to  $+1300^{\circ}\text{C}$ .

Set the function selector switch to “ $^{\circ}\text{C}$ ”.

Connect the sensor as shown below.



## 15 Specifications

Meas. Function	Measuring Range	Resolution	Input Impedance
			V(AC) / V(DC)
V $\overline{\text{---}}$	400.0mV	100mV	>20MW
	4.000V	1mV	11MW
	40.00V	10mV	10MW
	400.0V	100mV	10MW
	1000V	1V	10MW
V $\sim$	400.0mV	100mV	11MW
	4.000V	1mV	11MW
	40.00V	10mV	10MW
	400.0V	100mV	10MW
	1000V	1V	10MW
			Approx. Voltage drop at max. meas. current
A $\overline{\text{---}}$	40.00mA	10mA	450mV
	400.0mA	100mA	4.2V
	10.00A <sup>1)</sup>	10mA	750mV
A $\sim$	40.00mA	10mA	450mV
	400.0mA	100mA	4.2V
	10.00A <sup>1)</sup>	10mA	750mV
			Open-circuit voltage
$\Omega$	400.0W	100mW	approx 0.45V
	4.000kW	1W	
	40.00kW	10W	
	400.0kW	100W	
	4.000MW	1kW	
	40.00MW	10kW	
$\rightarrow$ )	400.0W	100mW	
$\rightarrow$ +	1.000V	1mV	approx 1V
F	5.000nF	1pF	
	50.00nF	10pF	
	500.0nF	100pF	
	5.000mF	1nF	
	50.00mF	10nF	
	200.0mF	100nF	
Hz <sup>2)</sup>			$f_{\min}$
	10.000Hz	0.001Hz	1Hz
	100.00Hz	0.01Hz	1Hz
	1.0000kHz	0.1Hz	1Hz
	10.000kHz	1Hz	1Hz
	100.00kHz	10Hz	1Hz
500.0kHz	100Hz	1Hz	
%	2.0...98.0%	0.1%	---
			<b>Sensor</b>
$^{\circ}\text{C}$	0...+1300 $^{\circ}\text{C}$	1 $^{\circ}\text{C}$	K-type NiCr-Ni

1) max. 12 A / 5 min. 16 A / 30 Sec

2) Indication for frequency measurement expanded to 9999 D

Meas. Function	Measuring Range	Digital display inherent deviation at reference conditions $\pm$ (...% of rdg + ...digits)	Overload capacity <sup>1)</sup>	
			Overload value	Overload duration
V $\overline{=}$	400.0mV	0.75+2	1050V(DC)	Continuous
	4.000V	0.5+2		
	40.00V			
	400.0V			
	1000V			
V $\sim$	400.0mV	1.5+5	1050V(AC) rms	Continuous
	4.000V	1+5		
	40.00V			
	400.0V			
	1000V	1+10		
A $\overline{=}$	40.00mA	0.8+2	480mA	Continuous
	400.0mA	1.5+5	4)	4)
	10.00A <sup>4)</sup>			
A $\sim$	40.00mA	1+5	480mA	Continuous
	400.0mA	2+5	4)	4)
	10.00A <sup>4)</sup>			
$\Omega$	400.0V	0.8+5	500V DC/AC rms	10 min
	4.000kV	0.8+2		
	40.00kV			
	400.0kV	1+5		
	4.000MV	2+5		
	40.00MV			
$\varpi$ )	400.0W	Acoustic signal for 0...<75W (approx)		
$\rightarrow$	1.000V	2+10		
F	5.000nF	3+40 <sup>2)</sup>	500V DC/AC rms	10 min
	50.00nF	2+10 <sup>2)</sup>		
	500.0nF	0.5+3 <sup>2)</sup>		
	5.000mF	1+2 <sup>2)</sup>		
	50.00mF	1.5+2 <sup>2)</sup>		
	200.0mF	5+10 <sup>2)</sup>		
Hz <sup>5)</sup>	10.000Hz	0.2+2	$\leq$ 1kHz : 1000V $\leq$ 10kHz : 400V $\leq$ 500kHz : 40V except 400mV	Continuous
	100.00Hz			
	1.0000kHz			
	10.000kHz			
	100.00kHz			
	500.0kHz			
%	2.0...98.0%	10Hz...1kHz : $\pm$ 5D 1kHz...10kHz : $\pm$ 5D/kHz		
$^{\circ}$ C	0...+1300 $^{\circ}$ C	2+3	500V DC/AC rms	10 min

1) At 0 $^{\circ}$ C... + 40 $^{\circ}$ C

2) With zero adjustmet "REL".

3) Time required for measurement approximately 60 seconds.

4) max. 12 A/5 min      16 A/30 s

5) Indication of the frequency measurement expanded to up to 9999 digits



## Reference Conditions

Ambient	
Temperature	+ 23 °C ± 2 K
Relative Humidity	45% ... 55%
Measuring Magnitude	
Frequency	Sine, 50 Hz
Measuring Magnitude	
Waveform	Sine
Battery Voltage	3 V ± 0.1 V

## Ambient Conditions

Working Temperature	
Range	-10 °C ... + 50 °C
Storage Temperature	
Range	- 25 °C ... + 70 °C
Climate Classification	2z/-10/50/70/75% (without batteries) in compliance with VDI/VDE 3540
Relative Humidity	45 ... 75%
Elevation	to 2000 m

## Display

LCD display field (58mmx31.4mm) with digital display and display of unit of measure, current type and various special functions.

## Digital

Display/Char. Height	7 segment digits / 15 mm
Number of Places	3 3/4 place $\triangleq$ 3999 steps
Overflow Display	" OL "
Polarity Display	" - " sign is displayed when plus pole is at " $\perp$ "
Measuring Rate	3 measurements/s

## Influence Quantity and Effects


Influence Variable	Influence Range	Meas. Magnitude/ Measuring Range	Influence Effect
Temperature	0 °C ... +21 °C and +25 °C ... +50 °C	V ---	0.1 x intrinsic error/K
		V ~	
		mA / A ---	
		mA / A ~	
		Ω	
		F	
		Hz	
		Duty(%)	
°C			

Influence Variable	Influence Range (max. resolution)	Frequency	Intrinsic Error at Ref. ±(... % of rdg. +... D)
Frequency V <sub>AC</sub>	4, 40, 400 V	20 Hz ... < 50 Hz > 750Hz... 1kHz	2 + 3
	400 mV, 1000 V	20 Hz ... < 50 Hz > 50 Hz ... 500 Hz	2 + 3


Influence Variable	Influence Range	Meas. Magnitude/ Measuring Range	Influence Effect
Relative Humidity	55 ... 75%	V ≈ mA / A ≈ Ω F Hz (%) °C	1x intrinsic error

Influence Variable	Interference Magnitude	Measuring Range	Attenuation
Common mode Interference Voltage	1000 V DC/AC 50 Hz sine	all V DC	> 100 dB
	1000 V DC	all V AC	> 100 dB
	1000 V AC 50 Hz sine	400 mV / 4 V AC	> 55 dB
		40 V AC	> 55 dB
		400 V AC	> 43 dB
1000 V AC		> 23 dB	
Series-Mode Interference Voltage	max.1000 V AC 50/60 Hz sine	V DC	> 43 dB
	max.1000 V DC	V AC	> 55 dB

AuX. Voltage influence:

(without  display) - all ranges except cap.: ± 8 D  
cap.range: ± 20 D

## Power Supply

Battery	2 x 1.5 V mignon cell zinc-carbon cell per IEC R6 alkaline manganese cell per IEC LR 6
Service Life	with zinc-carbon cell: approx. 300 hr. with alkaline manganese cell: approx. 600 hr.
Battery Test	Automatic display of the symbol “  ” when battery voltage falls below : approx. 2.4 V
<b>Fuse</b>	
Fuse for ranges up to 400 mA	FF 1.6 A / 600 V; 6.3 mm x 32 mm; protects all current measuring ranges up to 400 mA in
Fuse for 10 A Range	FF 16 A / 600 V; 6.3 mm x 32 mm Protects all current measuring ranges up to 10 A.

## Electromagnetic compatibility (EMC)

EMC Immunity:	IEC 61326-1:2012, Table A.1 IEC 61000-4-2 8KV atmosphere discharge. 4KV contact discharge. IEC 61000-4-3 3V/m
---------------	---

Short-term measured value deviation may occur during electro-magnetic interference thus reducing the specified operating quality.

<b>Electrical Safety</b>	IEC 61010-1-2010
Installation category	600V CAT III / 1000V CAT II
Pollution degree	2
High voltage test	3.7 kV~(IEC 61010-1-2010)

## Mechanical Design

Protection	For meter : IP 52 For Terminals : IP 20
Dimensions	W x H x D:
With Holster	86 mm x 188 mm x 53 mm
Without Holster	79 mm x 174 mm x 38 mm
Weight	approx. 0.480 kg with battery

## 16 Maintenance


*Attention:*

*Disconnect the instrument from the measuring circuit before opening the instrument to replace the battery or the fuse !*

### 16.1 Battery

Before initial start-up, or after storage of your instrument, make sure that no leakage has occurred at the instrument battery. Repeat this inspection at regular intervals.

If battery leakage has occurred, electrolyte from the battery must be carefully and completely removed and a new battery must be installed, before the instrument can be placed back into operation.

If the  symbol appears in the LCD display, you should change the battery as soon as possible. You can continue to take measurements, but reduced measuring accuracy may result.

### Replacing the Battery(ies)

Simply unscrew the battery compartment cover from base housing. No need to remove whole base housing.

Remove the battery from the battery compartment.  
Insert two new 1.5 Vignon cells in accordance with the polarity symbols in the battery compartment.

Screw the battery compartment cover to base housing. Dispose of the dead battery in an environmentally sound fashion.

## 16.2 Fuses

The 16 A fuse interrupts the 10 A current measuring range, and the 1.6 A fuse the mA current measuring ranges. All other measuring ranges continue to function.

If a fuse blows, eliminate the cause of the overload before placing the instrument back into operation!

### Replacement of Fuses

Unscrew the base housing cover from front housing. Remove the defective fuse with the help of, for example, a test prod, and replace it with a new fuse.

Screw the base housing cover to front housing.

Make certain that the new fuse makes good contact.

The following fuses may be used:

- for current measuring ranges up to 400 mA:  
type FF 1.6 A / 600 V~ ; 6.3 mm x 32 mm
- for the 10 A measuring range:  
type FF 16 A / 600 V~ ; 6.3 mm x 32 mm



### Attention!

Be absolutely certain that only the specified fuses as above are used. The use of fuse with different specifications may place the operator, the system & measuring instrument in danger. The use of repaired fuses or short-circuiting of the fuse holder is prohibited.

---

## Fuse Testing

- # Take out the fuse to be tested.
- # Set the selector switch to “ $\rightarrow$ ”.
- # press yellow function key to select “ $\rightarrow$ ”.
- # Plug the measurement cable into the “V,  $\Omega$ ,  $\rightarrow$ , F” socket.
- # Measure the resistance of fuse.
- # A continuous audible signal and the display of approx.  $10.2\Omega$ , indicate that the fuse for the mA current range is OK.
- # A continuous audible signal and the display of approx.  $0.0\Omega$  indicate that the fuse for the A current range is OK.

If a value other than those indicated above, or if overflow (“OL”) is displayed, the corresponding fuse must be replaced.

### 16.3 Housing

No special maintenance is required for the housing. Excessive contamination has an adverse effect on isolation and reduces input resistance. The surface must be kept clean for this reason. Use a slightly dampened cloth for cleaning. Avoid the use of cleansers, abrasives or solvents.

## 17 Repair and Replacement parts service

When you need service, Please contact;

### **RISHABH INSTRUMENTS PVT. LTD**

F-31, M.I.D.C area,

Satpur, Nashik- 422 007

Maharashtra, India

Phone (0253) 2202202, 2202162

Fax : 91 - 0253 - 2351064

E-mail : [marketing@rishabh.co.in](mailto:marketing@rishabh.co.in)

Web : [rishabh.co.in](http://rishabh.co.in)





**RISHABH INSTRUMENTS PVT. LTD.**

**Factory:** F-31, MIDC, Satpur, Nashik-422 007 India

Phone(0253) 2202202, 2202162

Fax : 91 - 0253 - 2351064, 2202302

E-mail : International: [exp.marketing@rishabh.co.in](mailto:exp.marketing@rishabh.co.in)

India: [marketing@rishabh.co.in](mailto:marketing@rishabh.co.in)

**[www.rishabh.co.in](http://www.rishabh.co.in)**

Printed in India, Subject to change without Notice