#### **Application Note**



## Boonton 4540 RF Power Meter Application in a Transponder Type Pulsed Radar System

#### Michael Mallo, Rockee Zhang and Andrew Huston

Radar Innovations Laboratory, the University of Oklahoma



### Abstract

The Boonton model 4540 Series is the instrument of choice for capturing, displaying and analyzing RF power in both the time and statistical domains. Applications include pulsed RF signals such as radar, TDMA and GSM, and pseudorandom or noise-like signals such as CDMA, WLAN and WiMAX. The 4540 Series is a single or dual channel RF Power Meter that can measure modulated or CW signals using peak and average Boonton power sensors. This application paper focuses on discussing the usage of the 4540 Series RF power meter in advanced radar system test and development, especially in developing and testing a transponder type radar system for aviation scenarios.

### Boonton 4540 RF Power Meter Application in a Transponder Type Pulsed Radar System

Generally, radars use both continuous wave (CW) and pulsed waveforms to detect and track targets. Similar to wireless communications, complicated modulations may be applied to the signal waveforms to improve range resolution and detection performance. The power sensors within the 4540 Series can cover the frequency band from 500 Hz to Ku band (18 GHz), which is the operating frequency band for most tracking radars and ground based weather radars. The high dynamic range (-70 to +44 dBm CW power or -55 to +20 dBm pulsed power) is useful for debugging the power level at all ranges of the RF sections in a radar system. Compared to similar products on the market, the 4540 Series has the advantage of time resolution (0.2ns), which can be useful to observe the detailed and transient power structures of the radar signal.

## Using the Boonton 4540 series at different stages of the radar transceiver

The block diagram of a generic pulsed Doppler radar transceiver is shown in Fig 1, where the baseband waveform generator produces the required waveforms and modulation schemes, the intermediate (IF) stage modulates the baseband waveforms up to the transmit frequency band and demodulate the received RF waveforms back to baseband.



Fig 1 - A generic diagram of pulsed Doppler radar transceiver

Even though the power meter is a relatively simple instrument compared to an oscilloscope, it can be used at the baseband to check: (1) the required waveform power level for the IF and conversion stages, (2) the 'power profile' of the baseband signal (associated with the waveform envelope) with respect to time, and (3) the power level before the ADC and DSP stages. This stage has a lower frequency coverage (< 200 MHz), but requires a relatively large dynamic range due to the IF amplification (generally 70-100

dB), which fits within the dynamic range performance of the 4540 Series. It is recommended that modulated mode is used when complicated baseband modulations, such as phase modulations, are involved and *pulse mode* is used when the baseband waveforms are pulsed with a relatively wide bandwidth. At the IF stages, signal powers before and after the mixers, which are primary concerns, are measured to ensure that the conversion loss falls within the required system budget. To address this problem, the power meter and sensor need to be well-calibrated before the measurement. Checking with the linearity data on the reference level test document (along with the user's manual) is a good approach. Finally, at the RF stage, the frequency is the highest and the signal power level can vary. It is necessary to check the projected power level at the desired measurement point to make sure there will be no damage to the power sensor. Another important application of the power meter at the RF front end is the transceiver self-calibration/ test functions widely used in today's weather radars. For this case, a portion of the transmit power is sampled and looped back into the receiver channels, comparing the received power with expectation gives a good indication of the transceiver RF chain. A wellcalibrated power meter is a good tool to give a fast diagnosis of the RF system budget and is useful for field-inspection at all stages of the transceiver chain.

# Measuring the Transponder-Radar Signal using the Boonton 4540 series

This section introduces a practical example of using the 4540 series power meter to measure a combined transponder-radar system. The signal waveforms of this system are organized in a complicated fashion: The RF section provides 1090 MHz transmit and receive signals at standard transponder operating frequency, which is a pulsed waveform encoded as Pulse-Position Modulation (PPM) with 0.5  $\mu$ s pulse widths. The pulses are transmitted in bursts every second, with each burst lasting 112  $\mu$ s. The profile of the radar transceiver system is shown in the Fig. 2(a).





(a) System setup



(c) Measuring transponder 'bursts'

(b) Time-domain waveform (from oscilloscope)

Millel -7.165 dbm Millel -7.165 dbm Millel <lows dbm<="" th=""><th>04040 Millyi -69,016 dBm Millyi -69,016 dBm</th><th>Na 60</th></lows>	04040 Millyi -69,016 dBm Millyi -69,016 dBm	Na 60
10 db/Div -29 dbm cent	Hisking 69.016 dites 1 db/Div 5.18 dites cant	Dielka 348.
		Mark +40
	Manadaulau	
-1000 us 200 us	/Dw 1000 us	

(d) Measuring sub-pulses within a signal burst

Fig. 2 - Using the 4540 RF Power Meter to measure baseband pulses

The Boonton 4540 RF power meter is used in the testing and debugging of the baseband and RF signal levels from the transceiver outputs (before transmit to high power amplifiers). The following detailed steps are followed during the measurements:

#### 1. Calibration

Two types of power sensors are used: 57318 Peak Power Sensor (peak power) and 51075A Power Sensor (CW average power). Both sensors fit the transponder frequency requirement (L-band) and the transceiver power level requirements. The special aspect of the waveform modulation in this case (PPM + short pulse PM) makes both sensors useful for power measurements. Boonton provides a sensor calibration measurement table along with the quick start guide. However, following the standard sensor calibration procedure in the manual first is recommended to guarantee accuracy. Ensure the system is warmed up at least 3 minutes before the calibration. The AutoCal option, accessible via the Calibration menu, performs the sensor calibration automatically.

#### 2. Pre-checking power levels

The signal power level from the transmitter output should not exceed 0 dBm. Be aware that the sensor itself cannot handle more than 20 dBm peak power. Maintaining transmitter output power below 10 dBm is preferable. Also, signals below -40 dBm peak power or -70 dB CW power cannot be sensed (only the instrument noise floor will be visible).

#### 3. Selecting the pulsed, CW power or statistical mode

The greatest challenge with this measurement is the need to check the 'burst' of pulses (1 sec period and 100 µs length) rather than a single sub-pulse within the burst. *Pulsed mode* is the best option for measuring this particular type of radar waveform. The reason is the power sensor limits the rise time (in this case approximately 100 ns), while a single pulse has a rise time of about 10 ns and a pulse width of 500 ns. Using *modulated mode* is better for looking at continuously modulated periodic signals. The 4540's *statistical mode* is an appropriate option for noise radar, which is continuous with a randomly fluctuating signal power.

#### 4. Adjusting time and power scales

Adjusting the time and power scales of the display area is a simple yet crucial task. A proper choice of axes is integral to effectively illustrate data. The available options depend upon the mode in use. While in *modulated mode* or *pulse mode*, the Time option is available from the Main menu. Within the Time menu are options to adjust the Time Base (10 ns/Div to 1 min/Div), Position (either Middle, Right, or Left or +/-30 div), Trig Delay (0 ns to 100  $\mu$ s), and Position Control (Preset or Vernier). To adjust the power scale while in *modulated mode* or *pulse mode*, the user must navigate to the Main/Channel menu and then select the desired input channel (Channel 1 or Channel 2). This brings up the options to adjust the Vert. Scale (0.1 to 50 dB/Div) and the Vert. Center (-100 dBm to

+100 dBm). Furthermore, the Units (dBm, Watts, Volts, dBV, dBmV, and dB $\mu$ V) can be selected from the Main/Channel/Extensions menu. While in *statistical mode*, the Time option on the Main menu is replaced with the Stat option. This new menu allows the user to adjust the horizontal axis, which is actually the power axis in *statistical mode*, via the Horiz. Scale (0.1, 1, 2, or 5 dB/Div) and Horiz. Offset (-50.00 to +50.00 dB) options. The vertical axis in *statistical mode* displays the range from 0.0001% to 100.0%.

#### 5. Observing power profile of pulse burst and single sub-pulse

In this specific radar application, several parameters are required due to the complexity of the signal. Total average power is always desirable, and was easily obtained in *modulated mode* using the 51075A Power Sensor, and is shown in Fig. 3(a). This mode displays the average power of -48.858 dBm as measured over the entire PRT (1 sec). This signal in particular is comprised of a 112  $\mu$ s train of 112 sub-pulses. Each sub-pulse has a pulse-width of 0.5  $\mu$ s and is positioned in either the first half or second half of each microsecond interval using PPM. Because of these signal parameters, it is desirable to obtain the characteristics of the pulse-train as well as the individual sub-pulses. These measurements are made using the 57318 Peak Power Sensor.

Fig. 3(b) shows an entire pulse-train in pulse mode. Notice the width of the 'pulse' at the top left corner of the screen (112  $\mu$ s). Also given are the peak and average powers over the course of the pulse train. Fig. 3(c) illustrates the time-resolution of the 4540 series. In this figure, the pulse-train is expanded so that several sub-pulses are visible. Notice that some are approximately 0.5 while others appear to be double that length. This is due to the PPM method used. The chosen parameters (pulse-width, rise-time, fall-time, peak power, pulse average power, and marker power ratio) are displayed at the top of the screen. The final measurement was performed in *statistical mode* using the 57318 Peak Power Sensor. This mode gives the probability as a percentage in the vertical logarithmic scale that the signal contains certain relative power levels.



(a) Average power measurement of pulse-



(c) Pulse-train sub-pulse power measurements in pulse mode

Stopped				
width 112			6.711 dbm	
Rise .			9.766 d0m	
And the second second second		idlat 3	2.193 de	
10 db.Chv				
-15 dBm cent				
	a hare a		decorporate	
and the second	a anna a an		distant and	
		1		
2 (1 ) I	1	1.5		
		1.2.1.1.1.1.2.1.1	1	
territering area and	a series to	a second second		
and in contrast of some states		Address of the	A sea and a set	
		THE PARTY	In Part of	
0.us	200 us/t	Div	2000 us	

(b) Power measurements of one burst of train in *modulated mode* pulse-train in *pulse mode* 



(d) Power measurements of pulse-train in statistical mode

Fig. 3 - Using the 4540 RF Power Meter in (a) modulated mode, (b) and (c) pulse mode, and (d) statistical mode

#### Summary

Power meter is an important tool for radar engineering. Boonton model 4540 Series Peak Power meter is a powerful yet lowcost tool for advanced radar system development and trouble shooting. Using this power meter for measuring a transpondertype radar signal with complicated pulse modulation scheme is demonstrated in this application note. Performing appropriate calibration, selecting correct measurement mode/power sensor, and correctly controlling the user interfaces are the key steps to ensure accurate power measurements. Comparing to similar product we have been used, this power meter has nice graphic interface, comprehensive functionality and easy-to-learn features, which are very appropriate for university laboratories and engineer training programs.

#### Wireless Telecom Group Inc.

25 Eastmans Rd Parsippany, NJ United States Tel: +1 973 386 9696 Fax: +1 973 386 9191 www.boonton.com

© Copyright 2010 All rights reserved.

Note: Specifications, terms and conditions are subject to change without prior notice.

