


SMARTCONTROL | ECS

Energy Management-System

3-349-778-03

2/5.19

SMARTCONTROL M-BUS Module PW80



Our instruction manuals are prepared with care, examined and continuously updated. No liability can be assumed for faulty information. Errors and omissions are excepted. GMC-I Messtechnik GmbH reserves the right to implement technical improvements to the function and/or the design of software and hardware products, and to revise instruction manuals at any time without notice.

The information provided in this brochure includes general descriptions and performance features only, which do not always apply to the application in actual practice, or which may change as the result of further development of the products. The desired performance features are only binding if they have been explicitly agreed upon contractually. We make explicit reference to the fact that hardware and software designations are, as a rule, protected by the brand name, trade mark and patent rights of the respective manufacturers.

Subject to change without notice • PDF version available on the Internet at www.gossenmetrawatt.com

Südwestpark 15
90449 Nürnberg, Germany
Phone: +49 (0) 911 8602-111
Fax: +49 (0) 911 8602-777
e-mail: info@gossenmetrawatt.com
Internet: www.gossenmetrawatt.com

M-BUS Level Converter Module PW80

Up to 80 Standard Loads (article no. Z301Y)



The module is an add-on for the GOSSEN METRAWATT **SMARTCONTROL, rev.3**. The slot provided for this module is at the middle on the left-hand side of the SMARTCONTROL PCB (see figure 1). The module is shipped together with a plug-in T250 mA fuse.


The level converter is capable of supplying up to 80 standard M-BUS loads. The actual number depends on the size of the M-BUS network. No additional power supply is required.

It must be assured that the SMARTCONTROL is supplied with 24 V DC; this voltage determines the M-BUS signal's low level.

Installation

1. Switch the SMARTCONTROL off.
2. Open the SMARTCONTROL (IP 65 variant: open the door / IP 20 variant: open the lid).
3. Insert the fuse and the module.

 <p>Figure 1</p>	<p>M-BUS port selector Slot for fuse Slot for M-BUS module Green power LED for M-BUS module</p> <p>First insert the fuse, and then the module.</p>
 <p>Figure 2</p>	<p>It must be assured that all of the module's pins are inserted into their corresponding sockets.</p>




Initial Start-Up and Testing


In order to test the M-BUS level converter for correct functioning, the port via which it will communicate must first be selected. This selection is made with jumper SV14 for the M-BUS Port Selector.

Either M-BUS (default) or Field2 can be selected.

M-BUS Port Selector, SV14



SV14, selection of **M-BUS** interface



SV14, selection of **Field2** interface

After making this selection, the SMARTCONTROL can be switched on.

!!! Important !!!

Do not touch the M-BUS module during operation. Under certain circumstances, this may result in destruction of the module.

The green LED to the left of the M-BUS module should now be lit up.



Figure 4

A multimeter connected to terminals M+ and M- at the 8-pole screw terminal should result in a reading of approximately 36 µV DC.

Communication can only be tested in combination with an M-Bus slave. The slave is connected to terminals M+ and M-. Polarity is irrelevant.

Creating an M-Bus Command with the SMARTCONTROL Manager

M-Bus commands	
Type	Synchronized: <input type="checkbox"/>
<input type="radio"/> Secondary	Address: <input type="text"/>
<input checked="" type="radio"/> Primary	Port: Default <input type="button" value="▼"/>
Page: <input style="width: 40px;" type="text" value="5B"/> <input type="button" value="▼"/>	Prod. by: <input type="text"/>
Baud: <input style="width: 40px;" type="text" value="2400"/> <input type="button" value="▼"/>	Version: <input type="text" value="FF"/> [Hex] <input type="button" value="Off"/>
Media: <input type="text"/>	<input type="button" value="▼"/> <input type="button" value="Off"/>
<hr/> <div style="display: flex; justify-content: space-around;"> <input type="button" value="Test"/> <input type="button" value="OK"/> <input type="button" value="Cancel"/> <input type="button" value="Help"/> </div>	

Select the “Primary” or “Secondary” addressing type and enter the address of the connected M-Bus device to the “Address” field.

Next to “Port”, select either “Default” or “Field2” depending on the M-BUS Port Selector setting, and select the corresponding baud rate as well.

After clicking the “Test” button, the data window for the M-BUS command appears.

MBus - Ausleseergebnis

Auslesung:	05.07.2013 14:18:04	Status:	00 No Error		
Hersteller:	WZG: Neumann & Co. Wasserz.	ID:	12114054		
Primär:	0	Medium:	Water		
Version:	3	Zugriffe:	45	Packetgröße:	58

Tabelle 1: Ausleseergebnis

N...	Wert	Einheit	Typ
1	36.965000	m^3	instantaneous
2	05.07.2013 14:36:00	date_time	instantaneous
3	20.09.2012 00:00:00	date	instantaneous
4	0.040000	m^3	instantaneous
5	20.09.2013 00:00:00	date	instantaneous
6	12608.000000	fabrication no.	instantaneous

Format kopieren Hex Frame Start Beenden

Read-out of the M-BUS device is begun by clicking the “Start” button. If everything functions correctly, the display shown to the left appears with the corresponding entries for the connected device.



The COL LED indicates overloading or data collision within the M-BUS network.

The Rx and Tx LEDs indicate data communication of the M-BUS module via the M-BUS network.

Technical Data

Parameter	Value
Supply voltage	24 V DC
Current consumption in the idle state (without bus load)	Approx. 27 mA
Power consumption in the idle state (without bus load)	< 0.5 W
Additional power consumption for 24 V DC power supply at max. M-BUS load	~ 5 W
M-BUS voltages	24 V (low) and 36 V (high) Low level is the same as supply voltage
M-BUS current-carrying capacity	150 mA (roughly 80 standard loads)
M-BUS short-circuit strength	PTC fuse at MB+
Baud rate	300, 2400 or 9600 bits per second
Dimensions	30 x 33 x 15 mm

Possible Errors

If the M-BUS voltage LED does not light up, check the following:

- Fuse
- Correctly installed firmware (especially for board type S3)
- Possible short-circuits in the M-BUS cable and/or excessive bus load (more than 80 devices)

When overloading occurs, the module is switched off by the main processor for several seconds in order to allow the resettable fuse to cool down. It's thus advisable to wait a few minutes before searching for other sources of error.

Repair and Replacement Parts Service Calibration Center* and Rental Instrument Service

If required please contact:

GMC-I Service GmbH
Service Center
Beuthener Str. 41
90471 Nürnberg, Germany
Phone: +49 911 817718-0
Fax: +49 911 817718-253
e-mail: service@gossenmetrawatt.com
www.gmci-service.com

This address is only valid in Germany.

Please contact our representatives or subsidiaries for service in other countries.

* **DAkkS Calibration Laboratory for Electrical Quantities**

D-K-15080-01-01 accredited per DIN EN ISO/IEC 17025

Accredited quantities: direct voltage, direct current value, direct current- resistance, - alternating voltage, alternating current value, alternating current active power, alternating current apparent power, DC power, capacitance, -frequency, temperature

Product Support Industry

If required please contact:

GMC-I Messtechnik GmbH
Product Support Hotline Industry
Phone: +49 911 8602-500
Fax: +49 911 8602-340
e-mail: support.industrie@gossenmetrawatt.com

Edited in Germany • Subject to change without notice • PDF version available on the Internet