

Data Sheet RISH CON-P

















RISH CON-P

Application

The RISH CON - P transducer is used to measure and convert active, reactive, apparent power, Phase angle & Power Factor of a Single-phase or Three-phase AC system with balanced or unbalanced load into a proportional load independent DC current or voltage output signal.

Salient Features

- True RMS measurement.
- Fully onsite programmable input voltage range & input current range
- On Site Configurable as Active / Reactive / Apparent Transducer / Phase Angle / Power Factor
- Onsite selectable output type(DC current / DC voltage)
- Single or Dual output
- Accuracy Class 0.2 (IEC / EN 60688) for Power
- Accuracy Class 0.5 (IEC / EN 60688) for Phase Angle / Power Factor
- Seven Segment LCD Display
- Rs485(Modbus) Communication
- Wide Auxiliary power supply

Accepts any input between 60V-300V AC/DC or 24V-60V AC/DC

- Output Response Time < 750 ms standard
- Fast and easy installation on DIN RAIL or onto a wall or in a panel using optional screw hole bracket
- Connection Terminal: Conventional Screw type.

Product Features

Measuring Input:

AC Voltage/Current input signal, sine wave or distorted wave form.

Analog Output (Single or dual):

Isolated analog output which can be set to voltage or current output onsite.

Accuracy:

Output signal accuracy **class 0.2** as per International **IEC / EN 60688** Standard.

Programmable Input/Output:

The Transducer can be programmed onsite using front key & display or through programming port (COM) or through RS 485.

LED Indication:

LED indication for power on and output type. (Current output: Red LED, Voltage output: Green LED).



Fig. 1 RISH CON - P

Display Module(Optional):

Optional 7 segment LCD display with backlit & keypad. For displaying measured parameter & onsite configuration of Input/output.

RS485 Communication(Optional):

Optional RS485 communication is available. For reading measured parameter & onsite configuration of input/output.

Symbols and their meaning:

X Input

Apparent /Active/Reactive

Power Factor / Phase Angle

X0 Start value of input

X1 Elbow value of input

X2 End value of input

Y Output DC Voltage / DC Current

Y0 Start value of output DC

Voltage / DC Current

Y1 Elbow value of output DC

Voltage / DC Current

Y2 End value of output DC

Voltage / DC Current

R_N Rated value of output burden

F_N Nominal Frequency









Version No. L 10/2020

Page No.:1 www.rishabh.co.in

RISH CON-P

Technical Specifications

Measured Parameter •

Active Power / Reactive Power / Apparent Power / Power Factor /Phase Angle.

Network Type Supported by Power transducer: Single Phase / 3 phase 3 wire Unbalanced / 3 phase 4 wire Unbalanced

3 phase 3 wire balanced / 3 phase 4 wire balanced

Network Type Supported by Power Factor & Phase Angle: Single Phase / (U12 I1) 3 Phase Balanced load

(U13 I1) 3 Phase Balanced load / (U23 I1) 3 Phase Balanced load

3 phase 3 wire balanced / 3 Phase 4 wire Balanced load

Nominal Voltage Input(UN):

Nominal input Voltage (AC RMS)

(PT Secondary range)

 $100 \text{ V} \leq \text{U}_{\text{N}} \leq 500 \text{ VL-L}$

PT Primary range 100V to 692.8 KVL-L

Nominal Frequency FN 25 Hz to 65 Hz

Nominal input Voltage burden < 0.6 VA per phase at U_N

Overload Capacity: 1.2 * U_N continuously,

2 * Un for 1 second, repeated 10 times at 10 minute intervals

(Un maximum 300V with power supply powered from measuring input).

Nominal Current Input(IN):

Nominal input Current burden

Nominal input Current (AC RMS)

(CT Secondary range)

 $1 A \leq I_N \leq 5 A$

< 0.2 VA per phase at IN

CT Primary range 1 A to 9999 A

Nominal Frequency FN 25 Hz to 65 Hz

Overload Capacity: 1.2 * In continuously,

10 * In for 3 second, repeated 5 times at 5 minute intervals.

50 * In for 1 second, repeated 1 times at 1 hour interval (Max 250 A).

Allowed measuring range end values X2 (calibration factor Xc):

With single phase AC active/reactive/apparent power $0.30 \le (X2/Rated Power) \le 1.3 \cdot U_N/\sqrt{3} \cdot I_N$ With 3-phase AC active/reactive/apparent power

(For single phase Rated Power= $U_N / \sqrt{3} \cdot I_N$) (For Three phase Rated Power= $\sqrt{3} \cdot U_N \cdot I_N$) $0.30 \le (X2/Rated Power) \le 1.3 \cdot \sqrt{3} \cdot U_N \cdot I_N$

Phase Angle & Power Factor measuring Range:

Minimum span 20° to Maximum Span 360°

Measuring Output Y(Single or Optional Dual): →

Output type Load independent DC Voltage , DC Current

On site selectable through DIP switches. Unipolar 0...20mA / 4...20mA OR 0...10V.

Bipolar -20mA....0....+20mA OR -10V....0....+10V

Output burden with DC current output

Load independent DC output

Signal

 $0 \le R \le 15V/Y2$

Output burden with DC voltage output

Signal

 $Y2/(2 \text{ mA}) \le R \le \infty$



RISH CON-P

Current limit under overload R=0 \leq 1.25 * Y2 with current output

≤ 100 mA with voltage output

Voltage limit under $R=\infty$ < 1.25 * Y2 with voltage output

≤ 30 V with current output

Residual Ripple in Output signal ≤ 1% pk-pk

Response Time < 750 ms

Auxiliary Power Supply:

AC/DC Auxiliary Supply 60V... 300 VAC-DC ± 5% or 24V...60V VAC-DC ± 10%

AC Auxiliary supply frequency range 40 to 65 Hz

Auxiliary supply consumption

60V...300 VAC-DC

≤ 8VA for Single output
≤ 10VA for Dual output

24V...60 VAC-DC

≤ 5 VA for Single output
≤ 6 VA for Dual output

Accuracy: (Acc. to IEC / EN 60688)

Basic Accuracy for power transducer 0.2*C

Basic Accuracy for Phase Angle & Power Factor transducer 0.5*C

Factor C (The highest value applies if calculated C is less than 1,then C=1 applies)

Linear characteristics:

Bent characteristics:

 $C = \frac{1 - \frac{Y0}{Y2}}{1 - \frac{X0}{X2}}$ or C=1

For $X0 \le X \le X1$ $C = \frac{Y1 - Y0}{X1 - X0} \cdot \frac{X2}{Y2}$ or C = 1

For X1 \leq X \leq X2 $C = \frac{1 - \frac{Y1}{Y2}}{1 - \frac{X1}{X2}}$ or C=1

Reference conditions for Accuracy:

For Power Transducer:

Ambient temperature 23°C +/- 1°C

Pre-conditioning 30 min acc. to IEC / EN 60688

Input Variable Voltage Rated / Current Rated

Input waveform Sinusoidal, Form Factor 1.1107

Input signal frequency 50 or 60Hz

Active / Reactive factor $\cos \Phi = 1 \operatorname{resp. Sin} \Phi = 1$

For Phase Angle & Power Factor Transducer:

Reference Value For Phase angle = 90° resp. For power factor = 0.5

Auxiliary supply voltage At nominal range

Output Load Rn = 7.5 V / Y2 \pm 1% With DC current output signal Rn = Y2 / 1 mA \pm 1% With DC voltage output signal

Miscellaneous Acc. to IEC / EN 60688









RISH CON-P

Output Characteristics:

Example of setting with Linear Characteristics:


X0/Y0 X2/Y2 ---- Limit of the output range

Example of setting with bent Characteristics:

X0 = Start value of input Y0 = Start value of output X1 = Elbow value of input

Y1 = Elbow value of output X2 = End value of input Y2 = End value of output

Note: End value(Y2) of output cannot be changed onsite.



Additional Error:

Temperature influence ± 0.2%/10°C

Influence of Variations:

As per IEC / EN 60688 standard.

Output stability

Safety:

Protection Class Protection

Pollution degree Installation Category Insulation Voltage

< 30 min

II (Protection Isolated, EN 61010) IP 40, housing according to EN 60 529 IP 20 ,terminal according to EN 60 529

Ш

1min. (EN 61010-1)

7700V DC, Input versus outer surface

5200V DC, Input versus all other circuits 5200V DC, Auxiliary supply versus outer surface and output

690V DC, Output versus output versus each other versus outer surface.

Installation Data:

Mounting position

Weight

Mechanical Housing Lexan 940 (polycarbonate)

Flammability Class V-0 acc. To UL 94, self extinguishing,

non dripping, free of halogen Rail mounting / wall mounting

Approx. 0.4kg

Connection Terminal

Connection Element Conventional Screw type terminal with indirect wire pressure

Permissible cross section of the connection lead

 \leq 4.0 mm² single wire or 2 x 2.5 mm² fine wire



RISH CON-P

Environmental:

Operating temperature $0^{\circ}\text{C...}23^{\circ}\text{C}$... 45°C (usage Group II)

Storage temperature -40 °C to 70 °C

Relative humidity of annual mean ≤ 75%

Altitude 2000m max

Ambient tests:

EN 60 068-2-6 Vibration

Acceleration ± 2 g

Frequency range 10....150...10Hz, Rate of frequency sweep 1 octave/minute

Number of cycles 10, in each of the three axes

EN 60 068-2-7 Shock

Acceleration 3 x 50g

3 shocks in each direction

IEC 1000-4-2/-3/-4/-5/-6

EN 55 011 Electromagnetic compatibility.

LED Indication:

ON LED	Aux.supply healthy condition	Green LED continuous ON
	Output1 voltage selection	Green LED continuous ON
O/P1 LED	Output1 current selection	Red LED continuous ON
O/P2 LED	Output2 voltage selection	Green LED continuous ON
	Output2 current selection	Red LED continuous ON

Electrical Connections:

Connection	Terminal details				
Measuring Voltage Input	UL1 UL2 UL3 N	2 5 8 11			
Auxilliary Power supply	~ , + ~ , -	13 14			
Measuring output - 1	+	15 16			

Connection	Terminal details			
Measuring Current Input	I1 I1' I2 I2' I3 I3'	1 3 4 6 7 9		
Measuring output - 2	+ -	17 18		











RISH CON-P

Electrical Networks



Terminal Details



Dimensions




Fig 3. (All dimensions are in mm.)



RISH CON-P

Programming

(Figs. 4 and 5)

Programming of transducer can be done in three ways:

- 1) Programming Via Front LCD & two keys.
- Programming Via optional RS485(MODBUS) communication port. (Device address,PT Ratio,CT Ratio,Transducer type,Password, communication parameter,Output Type & simulation mode can be programmed).
- 3) Programming Via Programming port available at front of RISH CON Transducers using optional PRKAB601 Adapter.


Programming Via Programming port (COM)

A PC with RS 232 C interface along with the programming cable PRKAB601 and the configuration software are required to program the transducer.

The connections between

PC \longleftrightarrow PRKAB 601 \longleftrightarrow Rish CON Transducer.

The power supply must be applied to transducer before it can be programmed.



The Configuration software is supplied on a CD. The programming cable PRKAB601 adjusts the signal level and provides the electrical insulation between the PC and RISH CON Transducers.

Configuring RISH CON Transducer:

To configure RISH CON Transducer Input / Output one of the three programming methods can be adapted along with mechanical switch setting (DIP switch setting on PCB).

DIP Switch Setting for OUTPUT:

Type of output (current or voltage signal) has to be set by DIP switch (see Fig.5).

For programming of DIP switch the user needs to open the transducer housing & set the DIP switch located on PCB to the desired output type Voltage or Current. Output range changing is not possible with DIP switch setting.

Refer below Fig. 5 for DIP switch setting.

The four pole DIP switch is located on the PCB in the RISH CON Transducer

DIP Switch Setting	Type of Output Signal			
ON [] [] [] [] 1234	load-independent current			
ON [] [] [] [] [] [] [] [] [] [load-independent voltage			

Fig. 5









Page No.:7 www.rishabh.co.in

Ordering Information

Product Code	CP41-	Х	Х	XX	XX	Х	Х	Х	Х	Х	00
Model	Programmable Power Transducer P										
System type	4WUB (Onsite Selectable 1Ph. 2W, 3Ph. 3W/4W & Balanced / 3 Unbalanced)										
Input Voltage	Programmable100500V	Programmable100500V 8F									
Input Current	Programmable 15A	Programmable 15A 75									
Power Supply	60-300 VAC/DC	60-300 VAC/DC		Н							
	24-60 VAC/DC		F								
Output	1 O/P			1							
	2 O/P			2							
Display Module	With Display				D						
Without Display					Z						
RS485 Module	With RS-485					R					
Without RS-485						Z					
Drogramming Cable	With - PRKAB 601						С				
Programming Cable	Without - PRKAB 601							Z			

Ordering Example – CP41-P38F75F1DRZ00 – Rish CON P, Programmable power transducer, 3Phase 4Wire, 100...500VAC, 1...5A, Aux 24-60 VAC/DC, 1 O/P, With display, With RS485, Without - PRKAB 601

Analog DC output options as below, to be specified while ordering only

Current Output	Voltage Output	DIP Option				
Standard Ranges						
0/420 mA	010 V	Yes				
-20020mA	nA -10010mA					
Optional factory set ranges						
010 mA	05 V	No				
05 mA	02.5 V	No				
02.5 mA	01 V	No				
01 mA						

Note:

- 1. End value of output can not be changed onsite.
- 2. -20...0...20mA and -10...0...10V output ranges are not applicable for Apparent power.







RISHABH INSTRUMENTS PVT. LTD.

Domestic (India): +91 253 2202028/99 | marketing@rishabh.co.in International: +91 253 2202004/06/08/99 | global@rishabh.co.in www.rishabh.co.in